



Innovation in Mobility

S-Series™
Export Use
Wheelchair and Standee Lift
with Folding Platform

Service/Owner Manual

(Owner Retains after Installation by Authorized RICON Service Technician)

09/07/00

32DSSE00.H

U.S. Patent Nos: 4,534,450, 5,308,215; 5,445,488; 5,605,431, 5,944,473;

Australian Patent No: 687066

Canadian Patent No: 1,245,603

Other U.S. and foreign patents pending.

©1994-00 RICON CORP.
All Rights Reserved

Printed in the
United States of America

This RICON product must be installed and serviced by authorized RICON service technicians.

Authorized RICON service technicians must refer to this manual for installation instructions.

The owner must refer to this manual for operating instructions, then retain it for future reference by authorized RICON service technicians who perform service and repairs.

Customer Name:	_____
Installing Dealer:	_____
Date Installed:	_____
Serial Number:	_____

REVISION RECORD

REV.	PAGE(S)	DESCRIPTION OF CHANGE	ECR / ECO
32DSSE00 .H 09/07/00	5-2	Updated pump in drawing SSX00001, added a bracket to drawing.	
	Cover	Added U.S. patent number 5,944,473	2859/ 4216
	5-2	Added a third hydraulic spool assy to dwg ssx00001 (ref # 13-3 and 14-3).	2896/ 4250
		Part number 25382 is replaced with 17901	3166/ None
	5-20,23	Deleted pins 14322 and VT-PI-44, plus ring 14-31-075; added note **** for pin kit 16679.	3201/ 4487
	4-5	Changed hydraulic oil to Texaco 01554.	3215/ None
	5-3, 4	Added harness V2-SH-006, decal 32-10-154, and poppet valve V2-SH-177.	None/ None
	5-16	Changed part # 28325 to 15988 (Bag of ten).	None/ None
	4-9, 10	Wiring diagrams redrawn to show second motor solenoid.	3343/ 4567
	5-15	Added two platforms; V2-PF-372 & V2-PF-383.	None/ None
	5-24	Added two models; S2034 & S2035	None/ None
END OF LIST			

I. INTRODUCTION	1-1
RICON 5-YEAR LIMITED WARRANTY	1-2
SHIPMENT INFORMATION	1-3
GENERAL SAFETY PRECAUTIONS	1-3
MAJOR LIFT COMPONENTS	1-4
II. INSTALLATION	2-1
A. MECHANICAL INSTALLATION	2-1
1. LIFT LOCATION	2-1
2. LIFT INSTALLATION GUIDELINES	2-1
3. LIFT INSTALLATION INTO VANS	2-2
4. LIFT INSTALLATION INTO BUSES	2-4
B. ELECTRICAL INSTALLATION	2-6
1. INSTALL MAIN CIRCUIT BREAKER	2-6
2. ROUTE/CONNECT MAIN POWER CABLE	2-7
3. GROUNDING INSTRUCTIONS	2-9
a. 12VDC Systems	2-9
b. 24VDC Systems	2-9
4. RICON UNSUPPORTED INTERLOCK DEVICE INSTALLATION	2-9
a. Interlock Method #1	2-10
b. Interlock Method #2	2-10
c. Interlock Method #3	2-11
C. FINAL ADJUSTMENTS	2-15
1. LIMIT SWITCH ADJUSTMENT	2-15
2. ROLLSTOP (PLATFORM TILT) ADJUSTMENT	2-17
3. TIE ROD ASSEMBLY INSTALLATION/ADJUSTMENT	2-17
4. PLATFORM PRESSURE SWITCH CHECK AND ADJUSTMENT	2-18
5. PLATFORM LOAD SENSOR SWITCH ADJUSTMENT	2-19
D. VERIFY INSTALLATION	2-20
E. CUSTOMER ORIENTATION	2-20

III. OPERATING INSTRUCTIONS	3-1
A. SAFETY PRECAUTIONS	3-1
B. DAILY SAFETY CHECK	3-2
C. LIFT FUNCTIONS	3-3
D. CONTROLS AND INDICATORS	3-4
1. CONTROL PENDANT	3-4
2. ELECTRICAL CONTROLS AND INDICATORS	3-4
a. Interlock Indicator Light	3-4
b. Circuit Breaker for Optional Door Operator	3-5
c. Control System Circuit Breaker	3-5
d. Main Circuit Breaker	3-5
3. MANUAL BACKUP PUMP	3-5
E. LIFT OPERATION	3-6
1. ENTERING VEHICLE	3-6
2. EXITING VEHICLE	3-7
3. STOWING PLATFORM	3-7
4. MANUAL OPERATION	3-8
a. Deploying Platform	3-8
b. Lowering Platform	3-9
c. Raise Platform	3-9
d. Stow Platform	3-9
F. MAINTENANCE AND REPAIR	3-9
IV. MAINTENANCE AND REPAIR	4-1
A. LUBRICATION	4-1
B. CLEANING	4-2
C. MAINTENANCE SCHEDULE	4-2
D. TROUBLESHOOTING	4-4
1. INTERLOCK INDICATOR DIAGNOSTICS	4-4
2. LIFT TROUBLESHOOTING	4-5
E. HYDRAULIC CIRCUIT DIAGRAM	4-6
F. ELECTRICAL WIRING DIAGRAM(S)	4-7

1. DIAGRAM LEGEND	4-7
a. Wire Color Codes	4-7
b. Electrical Connector Description	4-7
c. Diagram Labels	4-7
d. Electrical Symbols	4-8
2. S-SERIES™ LIMIT SWITCH STATE	4-8
3. WIRING DIAGRAMS	4-9
V. PARTS DIAGRAMS AND LISTS	5-1
APPENDIX 1. LIFT SPECIFICATIONS	5-24

LIST OF FIGURES	PAGE
FIGURE [1-1]: EXPORT USE WHEELCHAIR AND STANDEE LIFT W/ FOLDING PLATFORM	1-4
FIGURE [2-1]: PLATFORM MOUNTING	2-1
FIGURE [2-2]: FORD VAN CLAMPING BAR	2-2
FIGURE [2-3]: STEPWELL BRACKET	2-2
FIGURE [2-4]: BRACKET ASSEMBLY	2-3
FIGURE [2-5]: VAN BASEPLATE HOLES	2-3
FIGURE [2-6]: TOP BRACKET HOLES	2-3
FIGURE [2-7]: BUS CLAMPING BAR	2-5
FIGURE [2-8]: BUS BASEPLATE HOLES	2-5
FIGURE [2-9]: ELECTRICAL INSTALLATION DIAGRAM	2-6
FIGURE [2-10]: POWER CABLE ACCESS HOLE	2-7
FIGURE [2-11]: CABLE ROUTING	2-8
FIGURE [2-12]: CONTROL INTERFACE AND STRAIN RELIEF KIT #1007	2-8
FIGURE [2-13]: 24VDC WIRING	2-9
FIGURE [2-14]: INTERLOCK METHOD #1 DIAGRAM	2-12
FIGURE [2-15]: INTERLOCK METHOD #2 DIAGRAM	2-13
FIGURE [2-16]: INTERLOCK METHOD #3 DIAGRAM	2-14
FIGURE [2-17]: LIMIT SWITCH ADJUSTMENT DIAGRAM	2-15
FIGURE [2-18]: LIMIT SWITCH ADJUSTMENT CLEARANCE	2-15
FIGURE [2-19]: PLATFORM SET SCREWS	2-17

FIGURE [2-20]: ROD END INSTALLATION 2-17

FIGURE [2-21]: PRESSURE SWITCHES AT FLOOR LEVEL 2-18

FIGURE [2-22]: HYDRAULIC PUMP WITH PRESSURE SWITCH 2-19

FIGURE [2-23]: LOAD SENSOR ADJUSTMENT 2-19

FIGURE [2-24]: DECAL LOCATIONS AND PART NUMBERS 2-21

FIGURE [3-1]: DO NOT DEPLOY LIFT WHEN VEHICLE IS ON SLOPED GROUND 3-1

FIGURE [3-2]: FACE OUTWARD 3-1

FIGURE [3-3]: STAND CLEAR OF LIFT 3-2

FIGURE [3-4]: PLATFORM POSITIONS 3-3

FIGURE [3-5]: CONTROL PENDANT 3-4

FIGURE [3-6]: INDICATOR LIGHT/CIRCUIT BREAKERS 3-4

FIGURE [3-7]: MAIN CIRCUIT BREAKER 3-5

FIGURE [3-8]: MANUAL BACK-UP PUMP & HANDLE EXTENSION 3-5

FIGURE [3-9]: MANUAL OPERATION 3-8

FIGURE [3-10]: MANUAL BACK-UP PUMP - DEPLOY AND LOWER PLATFORM 3-8

FIGURE [3-11]: MANUAL BACK-UP PUMP - RAISE PLATFORM 3-9

FIGURE [4-1]: LIFT LUBRICATION POINTS 4-1

FIGURE [4-2]: S-SERIES™ HYDRAULIC CIRCUIT DIAGRAM 4-6

FIGURE [4-3]: MOLEX® CONNECTORS 4-7

FIGURE [4-4]: DIAGRAM SYMBOLS 4-8

FIGURE [4-5]: LIMIT SWITCH ACTUATION DIAGRAM 4-8

FIGURE [4-6]: WIRING DIAGRAM FOR LIFT W/O DOOR OPERATOR 4-9

FIGURE [4-7]: WIRING DIAGRAM FOR LIFT W/ DOOR OPERATOR 4-10

FIGURE [5-1]: MONARCH HYDRAULIC POWER UNIT #1 5-2

FIGURE [5-2]: MONARCH HYDRAULIC POWER UNIT #2 5-6

FIGURE [5-3]: S-SERIES™ HYDRAULIC SYSTEM 5-8

FIGURE [5-4]: S-SERIES™ ELECTRICAL SYSTEM 5-10

FIGURE [5-5]: S-SERIES™ PENDANT 5-12

FIGURE [5-6]: S-SERIES™ SPLIT PLATFORM 5-14

FIGURE [5-7]: S-SERIES™ TRAVELING FRAME 5-18

FIGURE [5-8]: S-SERIES™ STANDEE HANDRAIL (EXPORT) 5-22

LIST OF TABLES **PAGE**

TABLE [1-1]: S-SERIES™ LIFT COMPONENT TERMINOLOGY 1-5

TABLE [2-1]: LIMIT SWITCH ADJUSTMENT CHART 2-16

TABLE [3-1]: LIFT FUNCTIONS 3-3

TABLE [4-1]: MAINTENANCE SCHEDULE 4-2

TABLE [4-2]: INTERLOCK INDICATOR TROUBLESHOOTING GUIDE 4-4

TABLE [4-3]: LIFT OPERATIONAL TROUBLESHOOTING GUIDE 4-5

TABLE [4-4]: WIRE COLOR CODES 4-7