



*Innovation in Mobility*

**S-Series™**  
***Transit Use (ADA)***  
***Wheelchair and Standee Lift***

**Service/Owner Manual**

(Owner Retains after Installation by an Authorized RICON Service Technician)

09/07/00

32DSS00.M

U.S. Patent Nos: 5,228,538; 5,373,915; 5,308,215; 5,445,488; 5,605,431; 5,944,473  
Australian Patent Nos: 661127; 687066 Canadian Patent No: 2,129,821  
German Patent No: EP 0625896 B1 U.K. Patent No: EP 0625896 B1  
Other U.S. and foreign patents pending.

©1992-00 RICON CORP.  
All Rights Reserved  
Printed in the  
United States of America

**This RICON product must be installed and serviced by authorized RICON service technicians.**

**The authorized RICON service technician must refer to this manual for installation instructions.**

**The owner must refer to this manual for operating instructions, then retain it for future reference by authorized RICON service technicians who perform service and repairs.**

Customer Name:	_____
Installing Dealer:	_____
Date Installed:	_____
Serial Number:	_____

## REVISION RECORD

REV	PAGES	DESCRIPTION OF CHANGE	ECR / ECO
32DSS00. M 09/07/00	5-2	Added a third hydraulic spool assy to dwg sxx00001 (ref # 13-3 and 14-3)	002898/42 50
	5-15	Part number 25382 is being replaced with 17901	3166
	5-15,18	Deleted pins 14322 and VT-PI-44, plus ring 14-31-075; added note **** for pin kit 16679.	None/ 4487
	4-3, 5	Changed hydraulic oil to Texaco 01554.	3215
	5-3, 4	Added harness V2-SH-006, decal 32-10-154, and poppet valve V2-SH-177.	None/
	4-9, 10	Wiring diagrams redrawn to show second motor solenoid.	3343/ 4567
	5-23	Added new model, S5010.	NA/
<b>END OF LIST</b>			

<b>I. INTRODUCTION</b> .....	<b>1-1</b>
RICON 5-YEAR LIMITED WARRANTY .....	1-2
SHIPMENT INFORMATION .....	1-3
GENERAL SAFETY PRECAUTIONS .....	1-3
MAJOR LIFT COMPONENTS .....	1-4
<b>II. INSTALLATION</b> .....	<b>2-1</b>
<b>A. MECHANICAL INSTALLATION</b> .....	<b>2-1</b>
1. LIFT LOCATION .....	2-1
2. LIFT INSTALLATION GUIDELINES .....	2-1
3. LIFT INSTALLATION INTO VANS .....	2-2
4. LIFT INSTALLATION INTO BUSES .....	2-4
<b>B. ELECTRICAL INSTALLATION</b> .....	<b>2-6</b>
1. INSTALL MAIN CIRCUIT BREAKER .....	2-6
2. ROUTE/CONNECT MAIN POWER CABLE .....	2-7
3. PROPER GROUNDING INSTRUCTIONS .....	2-9
a. 12VDC Systems .....	2-9
b. 24VDC Systems .....	2-9
4. RICON UNSUPPORTED INTERLOCK DEVICE INSTALLATION .....	2-9
a. Interlock Method #1 .....	2-10
b. Interlock Method #2 .....	2-10
c. Interlock Method #3 .....	2-11
<b>C. FINAL ADJUSTMENTS</b> .....	<b>2-15</b>
1. LIMIT SWITCH ADJUSTMENT .....	2-15
2. ROLLSTOP (PLATFORM TILT) ADJUSTMENT .....	2-17
3. PLATFORM LOAD SENSOR SWITCH ADJUSTMENT .....	2-17
<b>D. VERIFY INSTALLATION</b> .....	<b>2-19</b>
<b>E. CUSTOMER ORIENTATION</b> .....	<b>2-19</b>

<b>III. OPERATING INSTRUCTIONS</b>	<b>3-1</b>
A. SAFETY PRECAUTIONS	3-1
B. DAILY SAFETY CHECK	3-2
C. LIFT FUNCTIONS	3-3
D. CONTROLS AND INDICATORS	3-4
1. CONTROL PENDANT	3-4
2. ELECTRICAL CONTROLS AND INDICATORS	3-4
a. Interlock Indicator Light	3-4
b. Circuit Breaker for Optional Door Operator	3-5
c. Control System Circuit Breaker	3-5
d. Main Circuit Breaker	3-5
3. MANUAL BACKUP PUMP	3-5
E. LIFT OPERATION	3-6
1. ENTERING VEHICLE	3-6
2. EXITING VEHICLE	3-7
3. STOWING PLATFORM	3-7
4. MANUAL OPERATION	3-8
a. Deploy Platform	3-8
b. Lower Platform	3-9
c. Raise Platform	3-9
d. Stow Platform	3-10
F. MAINTENANCE AND REPAIR	3-10
<b>IV. MAINTENANCE AND REPAIR</b>	<b>4-1</b>
A. LUBRICATION	4-1
B. CLEANING	4-2
C. MAINTENANCE SCHEDULE	4-2
D. TROUBLESHOOTING	4-4
1. INTERLOCK INDICATOR DIAGNOSTICS	4-4
2. LIFT TROUBLESHOOTING	4-5
E. HYDRAULIC CIRCUIT DIAGRAM	4-6
F. ELECTRICAL WIRING DIAGRAMS	4-7

1. DIAGRAM LEGEND .....	4-7
a. Wire Color Codes .....	4-7
b. Electrical Connector Description .....	4-7
c. Diagram Labels .....	4-7
d. Electrical Symbols .....	4-8
2. S-SERIES™ LIMIT SWITCH STATES .....	4-8
3. WIRING DIAGRAMS .....	4-9
<b>V. PARTS DIAGRAMS AND LISTS .....</b>	<b>5-1</b>
<b>APPENDIX 1. LIFT SPECIFICATIONS .....</b>	<b>5-24</b>

**LIST OF FIGURES****PAGE**

FIGURE [1-1]:	TRANSIT USE (ADA) WHEELCHAIR AND STANDEE LIFT .....	1-4
FIGURE [2-1]:	PLATFORM MOUNTING .....	2-1
FIGURE [2-2]:	FORD VAN CLAMPING BAR ARRANGEMENT .....	2-2
FIGURE [2-3]:	STEPWELL BRACKET .....	2-2
FIGURE [2-4]:	BRACKET ASSEMBLY .....	2-3
FIGURE [2-5]:	VAN BASEPLATE HOLES .....	2-3
FIGURE [2-6]:	TOP BRACKET HOLES .....	2-3
FIGURE [2-7]:	BUS CLAMPING BAR ARRANGEMENT .....	2-5
FIGURE [2-8]:	BUS BASEPLATE HOLES .....	2-5
FIGURE [2-9]:	ELECTRICAL INSTALLATION DIAGRAM .....	2-6
FIGURE [2-10]:	POWER CABLE ACCESS HOLE .....	2-7
FIGURE [2-11]:	CABLE ROUTING .....	2-8
FIGURE [2-12]:	CONTROL INTERFACE AND STRAIN RELIEF KIT #1007 .....	2-8
FIGURE [2-13]:	24VDC WIRING .....	2-9
FIGURE [2-14]:	INTERLOCK METHOD #1 DIAGRAM .....	2-12
FIGURE [2-15]:	INTERLOCK METHOD #2 DIAGRAM .....	2-13
FIGURE [2-16]:	INTERLOCK METHOD #3 DIAGRAM .....	2-14
FIGURE [2-17]:	LIMIT SWITCH ADJUSTMENT DIAGRAM .....	2-15
FIGURE [2-18]:	LIMIT SWITCH ADJUSTMENT CLEARANCE .....	2-15
FIGURE [2-19]:	PLATFORM SET SCREWS .....	2-17
FIGURE [2-20]:	PRESSURE SWITCH TEST AT FLOOR LEVEL .....	2-17
FIGURE [2-21]:	HYDRAULIC PUMP WITH PRESSURE SWITCH .....	2-18
FIGURE [2-22]:	LOAD SENSOR ADJUSTMENT .....	2-18
FIGURE [2-23]:	DECAL LOCATIONS AND PART NUMBERS .....	2-20
FIGURE [3-1]:	DO NOT DEPLOY LIFT WHEN VEHICLE IS ON SLOPED GROUND .....	3-1
FIGURE [3-2]:	FACE OUTWARD .....	3-1
FIGURE [3-3]:	STAND CLEAR OF LIFT .....	3-2
FIGURE [3-4]:	PLATFORM POSITIONS .....	3-3
FIGURE [3-5]:	CONTROL PENDANT .....	3-4

FIGURE [3-6]: INDICATOR LIGHT/CIRCUIT BREAKERS .....	3-4
FIGURE [3-7]: MAIN CIRCUIT BREAKER .....	3-5
FIGURE [3-8]: MANUAL BACKUP PUMP & HANDLE EXTENSION .....	3-5
FIGURE [3-9]: MANUAL OPERATION .....	3-8
FIGURE [3-10]: MANUAL BACK-UP PUMP - DEPLOY AND LOWER PLATFORM .....	3-9
FIGURE [3-11]: MANUAL BACK-UP PUMP - RAISE PLATFORM .....	3-9
FIGURE [4-1]: LIFT LUBRICATION POINTS .....	4-1
FIGURE [4-2]: S-SERIES™ HYDRAULIC CIRCUIT DIAGRAM .....	4-6
FIGURE [4-3]: MOLEX CONNECTORS .....	4-7
FIGURE [4-4]: DIAGRAM SYMBOLS .....	4-8
FIGURE [4-5]: LIMIT SWITCH ACTUATION DIAGRAM .....	4-8
FIGURE [4-6]: WIRING DIAGRAM FOR LIFT WITH DOOR OPERATOR .....	4-9
FIGURE [4-7]: WIRING DIAGRAM FOR LIFT WITHOUT DOOR OPERATOR .....	4-10
FIGURE [5-1]: MONARCH HYDRAULIC POWER UNIT #1 .....	5-2
FIGURE [5-2]: MONARCH HYDRAULIC POWER UNIT #2 .....	5-5
FIGURE [5-3]: S-SERIES™ HYDRAULIC SYSTEM .....	5-7
FIGURE [5-4]: S-SERIES™ ELECTRICAL SYSTEM .....	5-9
FIGURE [5-5]: S-SERIES™ PENDANT .....	5-11
FIGURE [5-6]: S-SERIES™ SOLID PLATFORM .....	5-13
FIGURE [5-7]: S-SERIES™ TRAVELING FRAME .....	5-15
FIGURE [5-8]: S-SERIES™ (ADA) TRANSIT HANDRAIL	
STANDARD OPTION (SUPPL.) S.N.'s 32000 and HIGHER .....	5-20
FIGURE [5-9]: S-SERIES™ (ADA) TRANSIT HANDRAIL	
STANDARD OPTION (SUPPL) S.N.'s 49648 and HIGHER .....	5-22



**LIST OF TABLES****PAGE**

---

TABLE [1-1]: S-SERIES™ LIFT TERMINOLOGY .....	1-5
TABLE [2-1]: LIMIT SWITCH ADJUSTMENT CHART .....	2-16
TABLE [3-1]: LIFT FUNCTIONS .....	3-3
TABLE [4-1]: MAINTENANCE SCHEDULE .....	4-2
TABLE [4-2]: INTERLOCK INDICATOR TROUBLESHOOTING GUIDE .....	4-4
TABLE [4-3]: LIFT OPERATIONAL TROUBLESHOOTING GUIDE .....	4-5
TABLE [4-4]: WIRE COLOR CODES .....	4-7